

蓝牙音箱说明书



一, 充电

外插5V为本机充电, 充电时LED灯常亮。

二, 开机/关机

开关拨到“ON”位置为开机, 拨到“OFF”位置为关机。

三, 按键操作

1, “M”

短按: 蓝牙/自拍/USB/TF/RADIO/AUX切换。

2, “M/V-”

长按: 为音量减。

短按: 收音模式为上一个台,MP3模式为上一首歌曲。

在自拍模式下短按 “M/V-” 键为自拍功能 (仅适于苹果系统手机)

3, “M/V+”

长按: 为音量加。

短按: 收音模式为下一个台,MP3模式为下一首歌曲。

在自拍模式下短按 “M/V+” 键为自拍功能 (仅适于安卓系统手机)

4, “M/”

MP3/收音/蓝牙状态时短按为播放/暂停; 收音状态时长按为自动搜台。

有来电时短按 “M/” 键为接听电话;

通话中长按 “M/” 键为挂机, 短按此键为“手机接听/蓝牙音箱接听”之间切换;

蓝牙静置时长按 “M/” 键为回拨上一个电话。

四, 自拍功能

1. 按“M”键, 从蓝牙模式转换到自拍模式;

2. 手机打开蓝牙, 搜索“shutter”, 点击连接;

3. 打开手机的拍照界面, 此时按“M/V-”或者“M/V+”按键进行拍照。

附: 安卓系统要求4.2.2以上版本, IOS要求6.0以上版本, 其它版本不支持;
手机有独立拍照按键的一般不支持。

Wireless Speaker Specification



一, charge

External 5V charge for this machine ,charging LED light

二, ON/OFF

Switch to the “ON” position to boot, the “OFF” position for shutdown.

三, The Key Operation

1, “M” Short press: Wireless / autodyne /USB/TF/RADIO/AUX switching.

2, “M/V-”

Long press: for the volume reduction.

Short press: radio model for the last station, MP3 mode is a song.

The self timer mode short press “M/V-” button for the self timer function (only for Apple mobile phone system)

3, “M/V+”

Long press: the volume and.

Short press: Radio Model for the next stage, the MP3 mode for the next song.

The self timer mode short press “M/V+” button for the self timer function (only for Android phones)

4, “M/”

MP3/ radio / Wireless state short press “play / pause. Radio status long press for the auto channel search.

Incoming short press the “M/” key to answer the phone

Long press “M/” to hang up the call, short press the “M/” key “to switch between phone calls / Wireless speakers answer”

Wireless status long press the “M/” key to dial back the last telephone

四, The Self Timer Function

click “M”, from the Wireless mode to the self timer mode

open the Wireless mobile phone, search for “shutter”, click on the link open mobile phone camera interface, press “M/V-” or “M/V+” button to take pictures

Attached: Android system requires 4.2.2 IOS requires version 6.0 and above, the other version does not support. Mobile phone with independent pictures button generally do not support.